If you are using a printed copy of this procedure, and not the on-screen version, then you <u>MUST</u> make sure the dates at the bottom of the printed copy and the on-screen version match.

The on-screen version of the Collider-Accelerator Department Procedure is the Official Version.

Hard copies of all signed, official, C-A Operating Procedures are kept on file in the C-A ESHQ

Training Office, Bldg. 911A.

C-A OPERATIONS PROCEDURES MANUAL

Text Pages 2 through 7

Hand Processed Changes

HPC No.	<u>Date</u>	Page Nos.	<u>Initials</u>
	Approved:	Signature on File	
	(Collider-Accelerator Departme	ent Chairman Date

S. Sakry

7.1.59 Regeneration of Cold Turbines "A" Train

1. Purpose

To provide instructions for regenerating the cold turbine "A" train on the RHIC 25 kW helium refrigerator. The procedure is used to warm the turbines and remove moisture. The procedure contains the following sections:

- 5.1 Regeneration of turbine 5A only.
- 5.2 Regeneration of turbine 6A only.
- 5.3 Regeneration of turbines 5A, 6A and heat exchanger HX7A.

2. Responsibilities

- 2.1 The Shift Supervisor, or an Operator designated by the Shift Supervisor, is responsible for conducting the procedure and providing documentation in the Cryogenic Control Room Log and in the Cryogenic Valve Log.
- 2.2 Should a problem arise in the process of the procedure, the Shift Supervisor shall report to the Technical Supervisor for instructions before continuing.

3. <u>Prerequisites</u>

- 3.1 The Operator shall be trained by the Shift Supervisor.
- 3.2 Operator shall be familiar with the refrigerator P&ID drawing 3A995009, the physical location of components on the refrigerator, and the refrigerator control pages found on the CRISP control system. Valves and equipment mentioned in this procedure will be found on drawing 3A995009.
- 3.3 The regeneration skid must be available for use.

4. Precautions

4.1 If there is liquid helium in the refrigerator pots, all personnel entering the refrigeration wing of 1005R must be ODH Class 1 qualified, have a Personal Oxygen Monitor (POM) and carry an emergency escape pack, if the refrigerator is operating.

5. <u>Procedure</u>

5.1	<u>Turbine 5A Only</u>	
	5.1.1	Date
	5.1.2	Ensure mechanical brakes are installed per <u>C-A-OPM 7.1.26</u> , " <u>Expander Brake System Installation and Removal.</u> "
	5.1.3	Ensure the following valves are closed:
		Process:
		H385A H397M
		Valves to Atmosphere, Relief Header or Pure Helium:
		H414M H695M H814M H795M H431M H700M H793M H412M H9184M
	5.1.4	Start the regeneration (regen) skid per <u>C-A OPM 7.1.36</u> , "Regeneration <u>System Normal Operation."</u>
	_ 5.1.5	Ensure that the regulator PR9182M has been replaced with the spool piece.
	5.1.6	Open the following valves:
		H430M H812M H393M H390A (Vanes) H9182M H395M
	5.1.7	Close regen manifold bypass valve H9100M.
	5.1.8	Turn on regen skid pre-heater.
	5.1.9	Monitor temperature at TT389H.

	5.1.10	When TT389H reaches 290° K, continue to regenerate for at least one hour. Hygrometer reading must be -20° C to -40° C and improving less than 0.5° C/hour.		
	5.1.11	Turn off regen skid pre-heater.		
	5.1.12	Open bypass valve H9100M.		
	5.1.13	Close the following valves:		
		H390A(Vanes) H9182M H812A H393M H395M H430M		
	5.1.14	Secure the regen skid per <u>C-A OPM 7.1.36</u> .		
	5.1.15	Install regulator PR9182M.		
	5.1.16	Purge expander 5A per <u>C-A OPM 7.1.24</u> , " <u>Cold Expander Purge</u> <u>Procedure.</u> "		
5.2	<u>Turbin</u>	nes 6A Only		
	5.2.1	Date		
	5.2.2	Ensure mechanical brakes are installed on turbine 6A per <u>C-A OPM</u> 7.1.26, "Expander Brake System Installation and Removal."		
	5.2.3	Ensure the following valves are closed:		
		<u>Process</u> :		
		H402A H410M H409M		
		Valves to Atmosphere, Relief Valve Header or Pure Helium:		
		H393M H700M H793M H795M H431M H695M H814M H395M H9192M		

	5.2.4	Start the regeneration (regen) skid per <u>C-A OPM 7.1.36</u> , "Regeneration <u>System Normal Operation."</u>	
	5.2.5	Ensure that regulator PR9190M has been replaced with the spool piece.	
	5.2.6	Open the following valves:	
		H430M H412M H414M H812M H9190M H464A (Vanes)	
	5.2.7	Close regen skid bypass valve H9100M.	
	5.2.8	Turn on regen skid pre-heater.	
	5.2.9	Monitor temperature at TT408H.	
	5.2.10	When TT408H reaches 290° K, continue to regenerate for at least one hour. Hygrometer reading must be -20° C to -40° C and improving less than 0.5° C/hour.	
	5.2.11	Turn off regen skid pre-heater.	
	5.2.12	Open bypass valve H9100M.	
	5.2.13	Close the following valves:	
		H464A(Vanes) H9190M H812M H414M H412M H430M	
	5.2.14	Secure the regen skid per <u>C-A OPM 7.1.36</u> , " <u>Regeneration System Normal Operation.</u> "	
	5.2.15	Install regulator PR9190M.	
	5.2.16	Purge expanders 6A per <u>C-A OPM 7.1.24</u> , "Cold Expander Purge <u>Procedure."</u>	
5.3	<u>Turbin</u>	es 5A, 6A and Heat Exchanger HX7A	
	5.3.1	Date	
	5.3.2	Ensure that mechanical brakes are installed on turbines per <u>C-A OPM</u> 7.1.26, "Expander Brake system Installation and Removal."	

 5.3.3	Ensure the following valves a	re closed:
	Process:	
	H385A	H410M
	H399M	H409M
	Valves to Atmosphere, Relie	Header or Pure Helium:
	H414M	H395M
	H814M	H9190M
	H431M	H700M
	H793M	H795M
	H9184M	H695M
 5.3.4	Start the regeneration (regen) System Normal Operation."	skid per <u>C-A OPM 7.1.36</u> , "Regeneration
 5.3.5	Ensure that the regulator PR9 piece.	182M has been replaced with the spool
 5.3.6	To avoid spinning turbines, e equal to pressure in expander	nsure pressure in HX7A is approximately s (within 0.5 atm).
 5.3.7	Open process valves H397M jumpered at valve).	and H402A(air line must be
 5.3.8	Open the following valves:	
	H430M	H812M
	H393M	H390A (Vanes)
	H9182M	H464A (Vanes)
	H412M	
 5.3.9	Close regen manifold bypass	valve H9100M.
 5.3.10	Turn on regen skid pre-heater	:
 5.3.11	Monitor turbine 6A outlet ter	nperature at TT408H.
 5.3.12		K, continue to regenerate for at least one hour –20°C to –40°C and improving less than
5.3.13	Turn off regen skid pre-heate	r.

		5.3.14 Open bypass valve H9100M.
		5.3.15 Close the following valves:
		H464A(Vane) H9182M H390A(Vane) H393M H812M H430M H412M
		5.3.16 Install regulator PR9182M.
		5.3.17 Purge expanders 5A, 6A and heat exchanger HX7A per <u>C-A OPM 7.1.24</u> "Cold Expander Purge Procedure."
		5.3.18 Close the following process valves:
		H402A (return air line to normal) H397M
		5.3.19 Secure regen skid per <u>C-A OPM 7.1.36</u> , " <u>Regeneration System Normal Operation.</u> "
6.	Docur	nentation_
	6.1	The check-off lines are for place keeping only. The procedure is not to be initialed or signed, it is not a record.
	6.2	The Shift Supervisor shall document the completion of the procedure in the Cryogenics Control Room Log.
7.	Refere	<u>ences</u>
	7.1	C-A OPM 7.1.26, "Expander Brake System Installation and Removal"
	7.2	C-A OPM 7.1.36, "Regeneration System Normal Operation"
	7.3	C-A OPM 7.1.24, "Cold Expander Purge Procedure"
8.	Attacl	<u>nments</u>
	None	